





## **DSF-34BSS00**

## SHOWER SET INSTALLATION INSTRUCTIONS





## Notes before installation:

- 1. Check to make sure you have all the parts before starting.
- 2. Make sure all supply lines are free of debris.
- 3. Ensure water pressure is between 20-125 PSI (Includes combination of hot and cold feed
- 4. Pictures in the manual are general in content and may not represent exactly your purchased faucet. If you are having difficulties please contact a professional plumber.
- 5. If you will be away from home for an extended period you should shut off the main water supply.







Adjustable Wrench Pipe Tape




lools you




Hexagon Wrench


Philips Screwdriver




Confirm the position of the valve and secure to a supported surface.




Connect the hot and cold supply lines to the valve as well as the lines to the tub and or shower. Make sure all lines are fixed and stable




Install protective cover to valve to keep it covered during finishing process




Please cut the size of the tile hole according to the size and shape of the protective cover (about 5mm bigger than the protective cover from each side). And please put the tile outside the wooden wall (please note that we keep the same central point for the tile hole with the protective cover)




Loosen the screw and remove protective cover.



Install decorative plate to valve with the screws provided tighten down to wall



Put on the handle, then tighten the screw.



Install the shower arm, shower head and flange to the fitting. (stick to the wall). Tighten the showerhead to the shower arm with the pipe tape. (Make sure the pipe tape with clockwise direction).



All valves pass air and water testing during manufacturing.

If needed, air test MUST be requested before installation under the guide of a professional plumber.

Air pressure MUST NOT exceed 145PSI (=IOKG).

