



















- DST-02835
- DST-02854
- UST-02322
- UST-02849
- UST-02850
- UST-02851

## Skirted Tub Installation Guide



**Plus:**

- Conventional woodworking tools and materials
- Drop cloth
- Mortar cement
- Construction adhesive
- 1/8" (3 mm) Spacers
- Plastic film (Optional)

<p>Make sure the subfloor is level.</p> <p>Provide drain access from below.</p> <p>Provide access to all plumbing connections.</p> <p>Observe all local building and plumbing codes.</p>	<p><b>1</b> Construct a plumb stud pocket. Refer to the specification sheet.</p> 	<p><b>2</b> Install the rough plumbing.</p> 	<p><b>3</b> Install the drain to the bath.</p> 	<p><b>4</b> <b>Mortar Bed Use:</b> Lay plastic film on wooden subfloors if desired to prevent water absorption.</p>  <p style="text-align: center; font-size: small;">Plastic film (Optional)</p>
<p>Set the basin area in 1" (25 mm) to 2" (51 mm) of mortar cement.</p> 	<p><b>Construction Adhesive Use:</b> Apply a generous amount of construction adhesive to the bath feet or base.</p> 	<p><b>5</b> Lift the bath into place. Verify level. Ensure that the feet or base are supported.</p> 	<p><b>6</b> Apply weight to the bath basin until the mortar or adhesive sets.</p>  <p style="text-align: center; font-size: small;">Apply weight evenly.</p>	<p><b>7</b> Connect the bath drain to the drain pipe. Position a protective liner in the bath basin.</p> 
<p><b>8</b> Drill small pilot holes through the flange at the studs.</p> 	<p><b>9</b> If there are gaps, fill them with a shim.</p> <div style="border: 1px dashed black; padding: 5px; margin: 5px 0;"> <p style="text-align: center; font-size: small;">Side View</p>  </div>	<p><b>10</b> Secure the flange to the studs with galvanized nails or screws.</p> 	<p><b>11</b> Secure 1/4" (6 mm) furring strips to the studs to be flush with the bath flange.</p> 	<p><b>12</b> Install water-resistant wallboard over the framing.</p>  <p style="text-align: center; font-size: small;">Water-Resistant Wallboard</p>
<p><b>13</b> Apply a 1/8" (3 mm) bead of 100% silicone sealant along the seams.</p>  <p style="text-align: center; font-size: small;">100% Silicone Sealant</p>	<p><b>14</b> Install the finished wall and deck to within 1/16" (2 mm) of the bath rim.</p>  <p style="text-align: center; font-size: small;">Finished Material</p>	<p><b>15</b> Apply 100% silicone sealant around the bath along the finished walls and deck.</p>  <p style="text-align: center; font-size: small;">100% Silicone Sealant</p>		

Need help? Call, email or visit us online.